



Instruction Manual  
**CSW-200-UL™ SERIES**  
HIGH TRAFFIC COMMERCIAL GATE OPERATOR

**UL325 UL991**  
compliant compliant



installation instructions and manual book  
for architects, general contractors and dealers

# U L L I S T I N G S   A N D   I N S T R U C T I O N S

---

## Installation Instructions Regarding the Gate Operator

A) Install the gate operator only when:

1) The operator is appropriate for the construction and the usage Class of the gate.

2) All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 4 feet (1.2 m) above the ground to prevent a 2 1/4inch (57.15 mm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.

3) All exposed pinch points are eliminated or guarded, and

4) Guarding is supplied for exposed rollers.

B) The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening.

C) The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.

D) The gate must be properly installed and work freely in both directions prior to the installation of the gate operator.

E) -

F) Controls must be far enough from the gate so that the user is prevented from coming in contact with the gate while operating the controls. Controls intended to be used to reset an operator after 2 sequential activations of the entrapment protection device or devices must be located in the line of sight of the gate outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.

G) All warning signs and placards must be installed where visible in the area of the gate.

H) For a gate operator utilizing a non-contact sensor such as a photo beam:

1) See instructions on the placement of non-contact sensor for each Type of application,

2) Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate still moving, and

3) One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.

I) For a gate operator utilizing a contact sensor such as an edge sensor:

1) One or more contact sensors shall be located at the leading edge, trailing edge and postmounted both inside and outside of a vehicular horizontal slide gate.

2) One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.

3) One or more contact sensors shall be located at the pinch point of a vehicular vertical pivot gate.

4) A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subjected to mechanical damage.

5) A wireless contact sensor such as the one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless contact sensor shall function under the intended end-use conditions.

## Important Safety Instructions

---

**WARNING - To Reduce the Risk of Injury or Death:**

**1. READ AND FOLLOW ALL INSTRUCTIONS!**

2. Never let children operate or play with gate controls. Keep the remote control away from children.

3. Always keep people and objects away from the gate while the gate is in operation. **NO ONE SHOULD CROSS THE PATH OF A MOVING GATE.**

4. Test the gate operator monthly. The gate **MUST** reverse on contact with a rigid object or stop when an object activates the non-contact sensors. After adjusting the force or the limit of travel, retest the gate operator, Failure to adjust and retest the gate operator properly can increase the risk of injury or death.

5. Use the emergency release only when the gate is not moving. Make sure the power for the gate operator is off.

6. **KEEP GATES PROPERLY MAINTAINED.** Read the manual. Have a qualified service person make repairs to the gate or gate hardware.

7. The entrance is for vehicles only. Pedestrians must use separate entrance.


**8. SAVE THESE INSTRUCTIONS.**

## UL LISTINGS AND INSTRUCTIONS

---

**Gate** – A moving barrier such as a swinging, sliding, raising lowering, rolling, or like, barrier, that is a stand-alone passage barrier or is that portion of a wall or fence system that controls entrance and/or egress by persons or vehicles and completes the perimeter of a defined area.


**Vehicular horizontal slide-gate operator (or system)** – A vehicular gate operator (or system) that controls a gate which slides in a horizontal direction that is intended for use for vehicular entrance or exit to a drive, parking lot, or the like.




Class I

**Residential vehicular gate operator – Class I** – A vehicular gate operator (or system) intended for use in a home of one-to four single family dwelling, or a garage or parking area associated therewith.

**Commercial/General access vehicular gate operator – Class II**  
– A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units) hotel, garages, retail store or other building servicing the general public.




Class II



Class III

**Commercial/General access vehicular gate operator – Class III** – A vehicular gate operator (or system) intended for use in a industrial location or building such as a factory or loading dock area or other locations not intended to service the general public.

**Restricted access vehicular gate operator – Class IV** – A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.



Class IV


## WARNINGS AND PRECAUTIONS

---



**The CSW-200 is for Vehicular Gate Use Only!**

**NOT for Use on Any Pedestrian:** Gateways,  
Doorways or Passageways.




**Owners Must Never Let Pedestrians Cross the Path, Step or Hang on the Gate!**



**Never Mount Any Gate Operating Device Accessible Through the Gate!**

## ELITE RECOMMENDED SETUP



**Recommended Gate Setup Configuration**

### **Pedestrians Must have a Separate Walkway!**

#### **CSW-200-UL**

1/2 hp Motor, 120 VAC, 4 amp.  
Maximum Gate Length – 18 ft.  
Maximum Gate Weight– 600 lbs.

#### **CSW-200-UL-DM**

Two-1/2 hp Motors, 120 VAC, 4 amp.  
Maximum Gate Length – 18 ft.  
Maximum Gate Weight – 600 lbs.

#### **CSW-200-UL-ST**

1/2 hp Motor, 120 VAC, 4 amp.  
Maximum Gate Length – 18 ft.  
Maximum Gate Weight– 600 lbs.



#### **CSW-200-UL-1HP**

Two-1/2 hp Motors, 120 VAC, 7.9 amps.  
Maximum Gate Length – 20 ft.  
Maximum Gate Weight– 1000 lbs.



**Be sure to read and follow all Elite and UL instructions before installing and operating any Elite products. Elite Access Systems, Inc. is not responsible for improper installations or failure to comply with local building codes.**


# CONCRETE PAD AND GATE ATTACHMENT



Sample Installation

# INSTALLATION LAYOUTS

*Sample Installation is Shown on Previous Page.*



Dimension (A) thru (E) are from the center of one pivot point to the center of another pivot point.

**Caution:** If the gate is longer than 18 feet, follow **Chart A : A-2**.

**Suggestion:** The dimension between the gate and the concrete pad is always 10 inches less than the dimension D.

**Example:** D = 42", If the dimension between the gate and the concrete pad is 32".

**Chart A**

	A	B	C	D	E	Distance
1	46"	35.5"	29.5"	35"	11"	45"
2	46.75"	35.5"	33.5"	42"	11"	37"
3	46.75"	37"	31.5"	40"	11"	41"
4	47.25"	37.25"	30"	37"	11"	45"
5	47"	35"	29.5"	32"	11"	45"
6	42.5"	33"	26.5"	28.5"	11"	41"

**Chart B**




	A	B	C	D	E	Distance
1	34.5"	34.75"	29.5"	35"	14"	43"
2	44"	36.5"	32.5"	42"	14"	32"
3	44"	37"	30.5"	40"	14"	40"
4	45"	37"	30.5"	37"	14"	43"
5	44.75"	35.75"	29.5"	32"	14"	44"
6	41"	39"	27.5"	28.5"	14"	41"

*\*Note - If this dimension is between 20 and 32 inches, Refer to Compact Installation Page*

# COMPACT INSTALLATION

## Compact Installation Only!

"DO NOT" Use These Measurements for a Standard Installation.




Follow the exact measurements, then cut the standard arm to meet the shorter measurements.



# GATE ARM INSTALLATION


Incorrect  
Installation




Correct  
Installation




Once the gate arm measurements are calculated:



weld the bracket on the gate.




Weld the longer arm.....




.....then weld the shorter arm.

**Weld Completely Around the Rectangular Tubes**

## ADJUSTMENT OF OUTPUT SHAFT





## ADJUSTING GATE TRAVELING DISTANCE




Release the red handle and open the gate to a distance desired. Loosen the screw. Turn plastic part until the half moon shape hits the limit switch. For closing cycle, do the same with the other plastic part.

For a more precise adjustment, you may use the set allen screw.

## CHOOSING MOVEMENT DIRECTION



## HOW TO CONNECT POWER (120V)




### WIRE GAUGE REQUIREMENT FOR 120 VAC POWER SUPPLY: 1/2 HP AND DUAL MOTOR ONLY

16 Gauge	14 Gauge	12 Gauge	10 Gauge	8 Gauge	4 Gauge
150 Feet	250 Feet	400 Feet	650 Feet	1000 Feet	2200 Feet

Caution: ELITE ACCESS SYSTEMS, INC. is not responsible for conflicts between the information listed in the above chart and the requirements of your local building codes. The information is for suggested use only. Check your local codes before installation.

# CLUTCH ADJUSTMENT




The adjustment is for a gate that is over 300 pounds and 12 feet long or longer. While the gate is closing, instantly an "open" command is given as shown above; the clutch may slip a bit, max. of 1/4 to 3/4 of a turn (slippage depends on the weight of the gate). If it does not slip, then readjust the clutch.

## IMPORTANT!


Installers are required to adhere to this procedure: The UL required Warning Signs must be installed in plain view and on both sides of each commercial gate installed. Each sign is made with fastening holes in each corner and should be permanently secured in a suitable manner. Also the warning sticker should be placed on the operator so it is clearly visible.



## TWO-WAY ADJUSTABLE REVERSING SENSOR



Adjusted by Qualified Service Personnel




**DO NOT TOUCH ALARM SENSOR**

The level of sensitivity has to do with the weight of the gate and the condition of installation.




**Too sensitive** = if the gate stops or reverses by itself.

**Not sensitive enough** = if the gate hits an object and does not stop or reverse.

**CAUTION:** If the power supply to the gate operator is less than 99 volts, adjust the alarm by turning the alarm adjustment counter-clockwise enough to actuate the alarm when obstructed but not sensitive enough for false triggering to occur.



## ADJUSTABLE TIMER




Timer can be set from 1 to 60 seconds (**Timer ON**), or for push open/push close type operation (**Timer OFF**).

**Timer OFF**


# MASTER AND SLAVE WITH TIMER ON

Master and Slave Boards are Interchangeable

Master Omni Board Primary Control for System




**Caution:** 115 volts per operator required




1. Connect **G** from master to **G** of slave.  
(G is the shield or a ground wire)
2. Connect **B** from master to **B** of slave.
3. Connect **A** from master to **A** of slave.
4. Turn timers on **BOTH** Omni boards to the "ON" position
5. Turn the **SLAVE** Timer adjustment all the way Counterclockwise
6. Use **MASTER** timer **ONLY** to select the desired time

## MASTER AND SLAVE WITH TIMER OFF



**Caution:** 115 volts per operator required




## PARTIAL MASTER/INDIVIDUAL CONTROL

IN ORDER FOR THE FOLLOWING OPERATION TO OCCUR, FOLLOW THE INSTRUCTIONS.

**EXAMPLE:** There is a double gate, the entry gate is to be opened with a radio transmitter and the exit gate with a free exit loop. Only one safety loop system is to open both gates, and a fire department switch should open both gates at the same time.

1. Connect the radio receiver to entry gate only.
2. Connect the exit loop to exit gate only.
3. Connect the safety loop to both entry and exit gates.
4. Connect the fire department switch to both entry and exit gates.

## INSTRUCTIONS FOR OPTIONAL SYSTEMS



1 & 2 – Open Command

3 & 4 – Stop Command

5 & 6 – Close Command

7 – Common

8 – Normally Closed

9 – Normally Open

Maglock or  
Solenoid

10 & 11 – Burglar Alarm Output

12 & 13 – Burglar Alarm Input


14 – Ground

15 – B

16 – A

Master/Slave  
RS485


## MASTER/SLAVE WITH OPTIONAL BOARD




Use this socket (M/S LINK) if the Omni option board is being used, and Master/Slave option is needed.





## SOLENOID CONNECTION WITH OPTIONAL BOARD



## MAGLOCK CONNECTION WITH OPTIONAL BOARD




# SOLENOID / MAG LOCK J3 CONNECTION




Connection of a Solenoid or Magnetic Lock can be made using the J3 plug and three wires supplied with the unit.


## Solenoid Lock




## Magnetic Lock




# HOUSE ALARM/PROXIMITY CONNECTIONS



Omni Option Board  
Elite Part # O-OMNI EXB





Use Low Voltage  
Wire 20 AWG



House Alarm


12VDC  
House Alarm System  
Dry Contact




Proximity Switch  
Elite Part # A PRS

2"  
Max.

## OPTIONAL BUILT-IN LOOP DETECTORS



## THREE PUSH BUTTON STATION




### Three Push Button System (OPEN-STOP-CLOSE)

- Step 1 - Cut off jumper wire #W4.
- Step 2 - Install Omni option board.
- Step 3 - Connect OPEN push button to # 1 & 2.
- Step 4 - Connect STOP push button to # 3 & 4.
- Step 5 - Connect CLOSE push button to # 5 & 6.

**CAUTION:** Make sure each push button is dry contact and there are no jumper wires between them.


# TERMINAL INPUT CONNECTIONS



## SAFETY LOOP SYSTEM

Allows gate to stay open when vehicles are obstructing gate path.


**Attention:**  
To connect loop detectors,  
*Refer to built-in  
loop detectors*  
or  
*Terminal Input  
connections.*



**Caution:** Suggested for vehicles 14 feet or longer. If a vehicle is shorter, a center loop system is recommended and should be installed.

## CENTER LOOP SYSTEM


Allows gate to stay open when vehicles are obstructing gate path.




**Caution:** This option is for all vehicles including ones less than 14' long. Center loop system requires two safety loops.

## EXIT LOOP SYSTEM

Allows gate to automatically open for exiting vehicles.




## ACCESS DOOR




**Access Door** - A generous allotment of space is allowed for external loop detectors and radio receiver. For a secure attachment, velcro external loop detectors in place.

## EMERGENCY RELEASE

---



### Grab the Gate to Make Adjustments




### Tighten the Red Handle, Replace the Cover and Bolt when Finished

When the power is turned on again, the gate will readjust itself automatically.



## REPLACING THE CONTROL BOARD




Disconnect 2 harnesses from OmniControl board. Unscrew 3 nuts to remove board.

## AUDIO ALARM

When one of the following events happens **Twice Consecutively**,  
**an Alarm will Sound!**




① The gate is too heavy or the arm is installed wrong, [Refer to Gate Arm Installation](#)



③ Gate hinges are too tight or broken and the gate is not moving freely.



② A foreign object is on the gate frame while the gate is moving.




⑤ The gate is moving and an object pushes the gate.



④ The gate hits the driveway, curb or other, and gets stuck or bent in an awkward position.

[Refer to the Troubleshooting Table](#)

## OPTIONAL DC - 1000 U BACK - UP



### Option A:


In case of power failure the gate opens automatically one time and stays open. when power is restored the operator returns to normal condition.

### Option B:

In case of power failure the gate will not open automatically until activated by a key switch or push button.

**for More Details  
Contact your Local Dealer**

## STOP BUTTON ALARM SHUT - OFF



Install the stop button in a secure accessible place.




This is an important command required to stop the audio alarm in case it has been triggered. Otherwise the alarm will sound for 5 minutes and reset itself.

### Use STOP Button:


- To stop the movement of the gate in case of potential entrapment.
- To reset the audio alarm, (check for obstructions).
- To stop the gate operator while traveling.

When using the Omni option board, use the "STOP" input to connect the stop button.

## UPHILL DRIVEWAY INSTALLATION



## SECONDARY ENTRAPMENT WIRING





If you are going to use a non-contact sensor as a secondary entrapment protection you should use a recognized component to component to comply with the revised UL 325 intended to be used in class I or class II gate operator, like the following: OMRON Retro-Reflective Photocell, Model: E3K-R10K4-NR

ELITE Part # **A OMRON**



# SECONDARY ENTRAPMENT MOUNTING

Elite Part # **A OMRON**





# TROUBLESHOOTING LED INFORMATION



## Resetting Motor



## Gate Will Not Close!



## Gate Will Not Open!




Consult your Authorized Technician for more help.

## TROUBLESHOOTING TABLE

CONDITION	POSSIBLE CAUSES	SOLUTIONS
<b>OVERLOAD LED ON And POWER LED OFF</b>	<ol style="list-style-type: none"> <li>Short circuit at terminals 8 and 10</li> <li>Short circuit at any of the loop detectors in the board</li> <li>Short circuit in the control board</li> </ol>	<ol style="list-style-type: none"> <li>Remove the short circuit condition at the terminals</li> <li>Remove the defective loop detector</li> <li>Send the board to repair</li> </ol>
<b>OVERLOAD LED ON And POWER LED ON</b>	<ol style="list-style-type: none"> <li>Excessive current draw at terminal 10</li> <li>Over-voltage at the 120 VAC line input</li> </ol>	<ol style="list-style-type: none"> <li>Reduce the accessories load from terminal 10</li> <li>Verify your electrical power</li> </ol>
<b>SYSTEM ON LED FLASHING</b>	<ol style="list-style-type: none"> <li>One limit switch is faulty</li> <li>Motor thermal fuse has popped-out</li> </ol>	<ol style="list-style-type: none"> <li>Test the limit switches and wire connections, fix the fault</li> <li>Reset the motor</li> </ol>
<b>REVERSE SENSOR LED ON</b>	<ol style="list-style-type: none"> <li>Gate has encountered an obstruction during traveling</li> <li>Reverse sensor is extra sensitive</li> </ol>	<ol style="list-style-type: none"> <li>Remove the obstruction</li> <li>Turn the reverse sensor switch counter clockwise a little more and try again</li> </ol>
<b>ALARM SENSOR LED ON</b>	<ol style="list-style-type: none"> <li>Gate encountered an obstruction during traveling</li> <li>Alarm sensor is extra sensitive</li> </ol>	<ol style="list-style-type: none"> <li>Remove the obstruction</li> <li>Turn the alarm sensor switch counter clockwise a little more and try again</li> </ol>
<b>ALARM SENSOR LED ON</b>	<ol style="list-style-type: none"> <li>Gate encountered an obstruction during traveling</li> <li>Alarm sensor is extra sensitive</li> </ol>	<ol style="list-style-type: none"> <li>Remove the obstruction</li> <li>Turn the alarm sensor switch counter clockwise a little more and try again</li> </ol>
<b>COMMAND PROCESSED LED ON</b>	<ol style="list-style-type: none"> <li>There is a command hold active</li> </ol>	<ol style="list-style-type: none"> <li>This is a normal response of the gate operator. It does not represent necessarily that there is a problem.</li> </ol>
<b>TIMER LED BLINKING And COMMAND PROCESSED LED BLINKING</b>	<ol style="list-style-type: none"> <li>There is a command holding the gate open</li> </ol>	<ol style="list-style-type: none"> <li>This is a normal response of the gate operator. It does not represent necessarily that there is a problem. Check inputs for command.</li> </ol>
<b>TIMER LED BLINKING, COMMAND PROCESSED LED BLINKING And REVERSE SENSOR LED ON</b>	<ol style="list-style-type: none"> <li>Gate has reopened because it encountered an obstruction while closing.</li> </ol>	<ol style="list-style-type: none"> <li>Any re-new command will resume normal operation. Check for obstructions.</li> </ol>
<b>AUDIO ALARM ON</b>	<ol style="list-style-type: none"> <li>Gate has encountered two consecutive obstructions while trying to close or open</li> </ol>	<ol style="list-style-type: none"> <li>Any re-new command will resume normal operation but not a radio command. Check for obstructions.</li> <li>You can stop the alarm by using the stop button.</li> </ol>
<b>ANY "LOOP LED" ON And NO VEHICLE ON THE SENSING AREA</b>	<ol style="list-style-type: none"> <li>The loop detector needs to be reset.</li> <li>The wire loop has been disrupted</li> <li>The loop detector needs to work in a different frequency</li> <li>The loop detector is too sensitive</li> </ol>	<ol style="list-style-type: none"> <li>Reset the loop detector (If you use Elite Plug-in Loop detectors, change the setting for sensitivity and come back to your original setting).</li> <li>Verify and correct connections</li> <li>Set a different working frequency</li> <li>Decrease the sensitivity of the loop detector</li> </ol>

# CSW - 200 PARTS



Note: \*Sold Individually, 2 Shown  
For Part Names, Refer to Parts Lis

# CSW - 200 PARTS LIST

<b>Kludge Assembly</b>	
<b>Q061</b>	<ul style="list-style-type: none"> <li>Q060 - ARM RELEASE HANDLE</li> <li>Q061 - OUTPUT SHAFT KLUDGE (T)</li> </ul>

<b>Swivel Arm</b>	
<b>Q103</b>	<ul style="list-style-type: none"> <li>Q198 - SWIVEL ONLY</li> <li>Q256 - SOLID ARM, SWIVEL, AND GATE CONNECTOR</li> </ul>

<b>CSW Arm Package</b>	
<b>Q104</b>	<ul style="list-style-type: none"> <li>Q038 - SHORT ARM</li> <li>Q040 - LONG ARM</li> <li>Q041 - ADJUSTABLE SOLID METAL</li> </ul>

<b>Limit Switch Assembly</b>	
<b>Q166</b>	<ul style="list-style-type: none"> <li>Q051 - COLLAR 1/2 In.</li> <li>Q052 - GATE ADJUSTMENT (PLASTIC PART)</li> <li>Q053 - BALL BEARING</li> <li>Q054 - GATE ADJUSTMENT SHAFT</li> <li>Q055 - LIMIT SWITCH HOLDER</li> <li>Q217 - SPROCKET GATE ADJUSTMENT</li> </ul>

<b>Flexible Assembly for 1/2 Horse Motor</b>	
<b>Q520</b>	WIRE HARNESS AND CONDUIT

<b>Flexible Assembly for Dual Motor</b>	
<b>Q521</b>	WIRE HARNESS AND CONDUIT

<b>Power Back-Up Unit</b>	
<b>O-DC-CSW</b> <b>O-DC-CSW DM</b>	<ul style="list-style-type: none"> <li>Q042 - DRIVE BELT (DM)</li> <li>Q123 - BACK-UP MOTOR DC 12V</li> <li>Q150 - CHASSIS DC BACK-UP</li> <li>Q163 - DRIVE BELT 4L240</li> <li>Q177 - WIRE HARNESS DC-1000</li> <li>Q209 - PULLEY DC-1000 1/2 ID</li> </ul>

<b>Electronic Box Assembly</b>	
<b>Q402 1/2 HP</b>	<b>Q403 1 HP</b>

- Q006 - PC BOARD NUTS (SET)
- Q018 - 1/2 HP ELECTRIC MOTOR
- Q019 - CONTROL BOARD NON UL (NOT SHOWN)
- Q025 - MOTOR PULLEY (ID5/8)
- Q027 - MOTOR CAPACITOR
- Q029 - LIMIT SWITCH
- Q044 - CHAIN #50
- Q045 - DRIVE BELT 1/2 HP 4L190
- Q046 - GEAR REDUCER PULLEY
- Q049 - SPROCKET (B50-16)
- Q059 - OUTPUT ARM SOLID
- Q062 - STAINLESS STEEL COVER
- Q063 - SECURITY BOLT
- Q084 - EMERGENCY KEY RELEASE
- Q112 - WIRE HARNESS-B TERMINAL BLOCK
- Q118 - KEY FOR ACCESS DOOR
- Q175 - BELT UL DM/1 HP
- Q208 - CLUTCH SET (POST 10/95)
- Q210 - GEAR BOX - SIZE 70
- Q212 - GEAR REDUCER 40-30:1
- Q213 - ENDLESS CHAIN #35 X 72P
- Q215 - OUTPUT SHAFT SPROCKET - 35B18
- Q216 - OUTPUT SHAFT FOR 70 REDUCER
- Q220 - CSW-200 CHASSIS FOR 70 REDUCER
- Q244 - UL COVER - DM HD POLYETHYLENE
- Q246 - NON UL COVER - DM HD POLYETHYLENE
- Q247 - UL COVER - DM HD POLYETHYLENE
- Q268 - KLUDGE COVER - PLASTIC
- Q269 - STAINLESS STEEL COVER
- Q400 - OMNI MAIN PCB
- Q401 - OMNI 1 HORSEPOWER BOARD<sup>#</sup>
- Q404 - OMNI ALARM
- Q408 - ELECTRONIC POWER STRIP
- Q409 - ELECTRONIC ACCESS PANEL
- A ELD - LOOP DETECTOR<sup>#</sup>
- O-OMNI EXB - OPTIONAL BOARD<sup>#</sup>

**Note:**

  Multiple Parts "O" Numbers

# OmniControl Board Accessories

\* Operator Serial No. and Model No. Required When Ordering

## MAINTENANCE

1. THE GATE AREA SHOULD BE KEPT CLEAN TO INSURE PROPER OPERATION.
2. MAKE SURE HINGES ARE WORKING SMOOTHLY AND LUBRICATED PROPERLY.
3. MAKE SURE GATE ARM IS GREASED PROPERLY.
4. KEEP THE COVER CLEAN.
5. CHECK BELT FOR CRACKING, LOOSENESS, WEAR.
6. CHECK GATE REVERSING SENSOR.
7. CHECK FOR PROPER CLUTCH ADJUSTMENT.
8. CHECK FOR PROPER SYNTHETIC OIL LEVEL IN UPPER GEAR BOX
9. FOR PARTS, [REFER TO CSW-200 PARTS PAGE](#) AND THIS PAGE.

**IF YOU NEED FURTHER ASSISTANCE, PLEASE CALL YOUR LOCAL SERVICE COMPANY.**



# AVAILABLE PRODUCTS

